




HP Pavilion dv6-1245dx RAM Replacement

If you want to increase the memory in your computer, or an internal memory card breaks, you can replace it with this guide.

Written By: Jaime



INTRODUCTION

In this guide, you will learn how to replace your RAM.



TOOLS:

- [Fingers](#) (2)
preferably human
- [Phillips #00 Screwdriver](#) (1)



PARTS:


- [HP Pavilion dv6-1245dx memory module](#) (1)

Step 1 — RAM




- Shut down the computer and unplug it from the outlet.
- ⓘ All screws removed in this guide will require a Phillips #00 screwdriver.

Step 2



- Turn the computer upside down.

Step 3



- Loosen the three screws from the memory module compartment cover
- ⓘ Screws will not come all the way out.

Step 4




- Remove the memory module compartment cover.

Step 5



- Remove the first memory module by spreading apart the two silver retaining tabs, using your thumb and index finger.
 - Pull and lift the green memory module upward at a 45-degree angle, and then pull the memory module out of the computer.
- ⓘ If you are replacing both memory cards, repeat this step with the bottom memory card.

Step 6



- To replace the memory card, insert the card at a 45-degree angle, then push into slot.
 - Push down gently so the silver retaining tabs click back into place.
- ⓘ If you are replacing both memory cards, replace the bottom card (closest to the system board) first.

To reassemble your device, follow these instructions in reverse order.

